



Connections



Insert the 2 wired plugs into the connectors on the module.

Note the orientation of the plugs, the metal connectors go to the bottom



Details

This unit will accept an AC or DC input. The polarity of the connections can be either way when using DC.

The input voltage should be at least 2 volts greater than the desired output voltage and in the range of 4 to 35 volts. Exceeding 35 volts could damage the unit.

The output voltage is adjusted by the preset shown above. Turning the preset clockwise will increase the output voltage, turning anti-clockwise will reduce the output voltage.

The intensity of the Output Indicator broadly reflects the output voltage. The higher the voltage the brighter the indicator. Note, the indicator may be very dim or not even visible for output voltages below 1.8 volts.

IMPORTANT

Purchasing the unit with a preset output voltage (i.e. 3V, 5V, 9V or 12V).

Check the output voltage with a multi-meter before making any connections. The output voltage will vary depending on the input voltage used. Turn the preset as described above to make any minor adjustments.

Preset outputs for 3, 5 and 9 volts are factory set using an input of 12 volts. A preset 12 volt output is set using an input voltage of 15 volts.

Microminiatures Ltd

Unit 4 MB Site, Norwich Road, South Burlingham, Norwich, Norfolk NR13 4EZ
Telephone 01493 753 283 Fax 01493 751 724 Email sales@microminiatures.co.uk

www.microminiatures.co.uk